



29.03.2016 Seite 1 / 3

DMR108

Akku-Baustellenradio



Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.	Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.
1	SE00000437	1	Leitung	1	48	SE00000177	12	Griffhalter rechts	1
2	SE00000325	1	Schraube 3x8	3	49	SE00000179	13	Griff	1
3	SE00000477	50	Elektronikbaustein A	1	50	SE00000180	12	Griffhalter links	1
4	SE00000325	1	Schraube 3x8	6	51	SE00000176	1	Schraube PTHE6x20 CR	1
5	SE00000480	38	Elektronikbaustein C	1	52	SE09176166	1	Sechskantschraube M6x16	1
6	SE09090011	1	Schraube 1,7	4	53	SE00000184	1	Feder	2
7	SE00000333	2	Tasterleistenhalterung	1	54	SE09994007	1	Kugel	2
8	SE00000334	5	Tasterleiste	1	55	SE023PC020	1	Eva 25x18x5,5	1
9	SE09090011	1	Schraube 1,7	5	56	SE00000445	1	Schraube 3x45	1
10	SE00000336	2	Tasterleistenhalterung	1	57	SE09994007	1	Kugel	2
11	SE00000337	5	Tasterleiste	1	58	SE00000184	1	Feder	2
12	SE00000325	1	Schraube 3x8	3	59	SE09176166	1	Sechskantschraube M6x16	1
13	SE00000339	17	Elektronikbaustein Antenne	1	60	SE00000187	2	Griffplatte rechts	1
14	SE00000325	1	Schraube 3x8	2	61	SE00000445	1	Schraube 3x45	1
15	SE00000239	3	Linsenhalter	1	62	SE00000192	2	Griffplatte links	1
16	SE00000193	1	Schraube M3x10	2	63	SE00000485	29	Gehäuse	1
17	SE00000343	15	Elektronikbaustein USB	1	64	SE00000395	16	Antenne	1
18	SE09064161	1	Schraube M4x16	1	65	SE00000398	1	Antennenhalter	1
19	SE00000325	1	Schraube 3x8	4	66	SE00000396	1	Antennenanschluss	1
20	SE09064161	1	Schraube M4x16	1	67	SE00000325	1	Schraube 3x8	1
21	SE00000347	24	Frontblende	1	68	SE023PC020	1	Eva 25x18x5,5	1
22	SE09064161	1	Schraube M4x16	1	69	SE00000403	3	Abdeckung Stromanschluss	1
23	SE00000325	1	Schraube 3x8	1	70	SE00000404	1	Schraube 3x14	1
24	SE09064161	1	Schraube M4x16	1	71	SE021PC030	1	Welle f. Batteriefachdeckel	1
25	SE00000351	25	Stossschutz Frontblende	1	72	SE00000406	4	Dichtung	1
26	SE00000160	1	Schraube PTHE6x47 CR	4	73	SE00000407	23	Lautsprecher Rechts	1
27	SE0338PC5Z	18	Frontbügel	2	74	SE00000408	13	Lautsprecherabdeckung	1
28	SE00000355	4	Abdeckung USB / 3,5mm Klinke	1	75	SE024J9040	1	Dichtungsring	4
29	SE00000356	1	Abdeckung	1	76	SE9076146A	1	Sechskantschraube M6x14	4
30	SE21B1110A	1	Ring	1	77	SE9076146A	1	Sechskantschraube M6x14	4
31	SE00000482	4	Einstellknopf	1	78	SE024J9040	1	Dichtungsring	4
32	SE09176166	1	Sechskantschraube M6x16	2	79	SE00000408	13	Lautsprecherabdeckung	1
33	SE00000357	21	Stossschutz Rückseite oben	1	80	SE00000438	23	Lautsprecher Links	1
34	SE00000359	17	Stossschutz Rückseite unten	1	81	SE00000406	4	Dichtung	1
35	SE09176166	1	Sechskantschraube M6x16	2	82	SE00000416	11	Baustein E	1
36	SE00000362	10	Verriegelungsplatte	1	83	SE00000325	1	Schraube 3x8	2
37	SE00000364	1	Stift 73,5mm	1	84	SE00000200	4	Baustein C	1
38	SE00000365	1	Verschlussleiste	1	85	SE00000325	1	Schraube 3x8	2
39	SE00000483	24	Batteriefachdeckel	1	86	SE00000423	14	Baustein AUX IN	1
40	SE00000369	1	Stift 64,5 mm	1	87	SE00000193	1	Schraube M3x10	2
41	SE00000325	1	Schraube 3x8	2	88	SE00000199	1	Silikonscheibe	1
42	SE00000371	13	Dichtung	1	89	SE00000325	1	Schraube 3x8	1
43	SE0307PC5Z	3	Batteriefachdeckel Mignon	1	90	SE00000199	1	Silikonscheibe	1
44	SE00000466	1	Batteriekontakt (+)	1	91	SE00000325	1	Schraube 3x8	1
45	SE00000467	1	Batteriekontakt (-)	1	92	SE00000422	5	Lautsprecherhalterung	1
46	SE021E9030	1	Batteriekontakt +/-	1	93	SE00000430	1	Schalterknopf	1
47	SE00000176	1	Schraube PTHE6x20 CR	1	94	SE00000488	20	Baustein Batterieumschalter	1



29.03.2016 Seite 2 / 3

DMR108

Akku-Baustellenradio



Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.
95	SE00000422	5	Lautsprecherhalterung	1
96	SE00000325	1	Schraube 3x8	2
97	SE00000433	17	Baustein DC Eingang	1
98	SE09090011	1	Schraube 1,7	2
99	SE00000435	1	Bausteinhalter DC Eingang	1
100	SE00000473	13	Kontaktplatte 10.8V	1
101	SE00000325	1	Schraube 3x8	1
102	SE00000195	1	Kabelbinder 100mm	3
103	SE024PC040	5	Dichtung	1

*** Zubehör ***

Z	SE00000101		Steckernetzteil	1
---	------------	--	-----------------	---



29.03.2016 Seite 3 / 3

DMR108

Akku-Baustellenradio

